



BB1394 GAFF TOGGLE

Designed for use on 14 -16 foot boats this toggle is 3 1/4" long, 3/4" wide and 1/8" thick. It is intended to penetrate completely thru the gaff jaws.




HM0059 GAFF TOGGLE

Gaff Toggles are used at the forward end of the gaff in the center of the gaff jaws. They are the attachment point for the throat halyard and when extended completely through the gaff the attachment point for the head of the mainsail.




HM0027 COAMING BRACKETS

These angled brackets are sold in sets (Port & Stbd.) and are used between the transome and the coaming on the Herreshoff 12 1/2 and Fish Class Boats.



BB2496 HALYARD MAST FAIRLEADERS

Usually used as shown to sway up halyards on smaller boats this useful fitting has many other uses. When mounted horizontally on the aft size of the spreaders they can be used at the mooring to flip the halyards over to prevent halyard slap.



HM7899

HM7898



BB0597 RAIL SUPPORT

This fitting can be used on the tops or sides of cabins or in companion ways. With two supports and a strong piece of wood (oak or teak) in between you have an excellent grab rail. This fitting is 3 3/8" wide, 2 1/2" high and uses a 1 3/16" Dia. piece of wood.

